

## Care and Maintenance Instructions

### CONGRATULATIONS ON THE PURCHASE OF YOUR NEW ACRYLIC LINER!

The following cleaning instructions have been compiled for proper hassle-free maintenance.

#### **General cleaning instructions:**

For normal everyday cleaning, Luxury suggests the use of a mild soap and water, with a soft wash cloth. Use of scouring pads or abrasive cleansers will dull the surface. Should you wish to use a product not listed below, test on a small area in the corner of the skirt before applying to the entire bathtub liner. Always review individual cleansers' instructions. **Always rinse thoroughly after cleaning.**

**Recommended cleaner:** "Dawn" dishsoap & water, Formula 409. Vinegar and water may also be used to soften water minerals. **Diluted** Clorox Bleach may be used as a disinfectant.

#### **Do not use\***

Original Clean Shower, Clean Shower for Plastic Showers & Glass, Soft Scrub, Dow disinfectant cleaner, Scrub Free, Lysol disinfectant cleaner, acetone, Lestoil, ammonia, fingernail polish remover, aerosol cleaners, or scouring pads.

\*Use of the chemicals will cause a dull surface and/or an easily recognizable chemical crack. This will void your product warranty.

**There is no need to use abrasive cleaners. Abrasive cleaners dull the gloss over a period of years. In extreme cases where the recommended cleaners do not work, use a Chore Boy or 3M Sponge pad. Make sure you use only the ones recommended for Teflon or non-stick surfaces.**

#### **Drain cleaner:**

Caution: liquid drain cleaners are recommended over powders and/or crystal; however, when using liquid drain cleaning agents, bail the standing water out of the bathtub and remove the drain plug. Use a funnel to prevent spills and apply the chemicals directly down the drain. Always make certain that chemicals do not come in contact with the acrylic surface. Use drain cleaners sparingly, so that they do not boil out and attack the acrylic surface.

### **Removal of standard drain plug:**

Occasionally your drain may slow down due to hair, etc., in the cross bars. In order to remove the standard drain plug, you must:

1. Push it down in the closed position
2. Turn the knob counter-clockwise, and remove it. Under the knob there is a stationary brass peg;
3. Turn the peg counter-clockwise using a flat tip screwdriver or a pair of pliers.
4. When you remove the peg, the drain plug will also come out.
5. Remove any obstacles from the crossbars.

### **Removing light scratches, abrasions, etc.:**

Should you accidentally use an abrasive cleaner or incur a minor scratch in your new acrylic bathtub liner, it may be restored to its original glossy finish. You can do this by using an approved acrylic repair kit available through your Luxury Bath dealer. Should you wish to use any other polishing waxes or compounds, please test in a corner area of the skirt that is not highly visible.

Should you have any further questions, feel free to contact our office at **(800) 354-2284**

